

CONNEXION AO

Instruction for "THE COMPLETE"



- 1- The RCA 90° goes on the machine, this is important to avoid any short-circuit.
- 2- The right RCA goes on your connection on the visor.
- 3- As the magnets are very powerful and so as not to damage the visor and snowmobile connections, we ask to install a **wire clamp** 🖱 at each end of "the Complete" one on the snowmobile near the electrical outlet, and the other on your helmet near the visor connection.
- 4- Here's how to unplug. Take this side of the magnetic connector and pretend you want to bend it. See the photo



*The 2 wire clamps are provided

**90-day warranty
(Starts after the winter season begin)

To see the instructions completes,
Go to
WWW.CONNEXIONAO.CA

